

RS232 Protocol


RS232 Cable

- Using RS232 Cable



RS232 Port Schematic

- RS232 Input Schematic



RS232 Command:

1.The virtual serial port should be configured as follows.

Bits per second – 19200

Data bits – 8

Parity – None

Stop bits – 1

Flow control – None

2. An explanation of the content transmitted to the display

Tx: [line 1] BE EF 03 19 00 HH HH II JJ JJ CC CC FF FF FF FF

Tx: [line 2] KK 00 00 00 CC CC CC CC CC CC CC CC CC CC CC CC

BE EF – signifies the beginning of the transmission (always BE EF)

03 – indicates the packet type (typically 03 in this application)

19 00 – indicates the packet length (typically 19 00 in this application)

HH HH – gives the calculated CRC checksum for the transmission

II – gives the operation type

JJ JJ – gives the operation name (least significant byte is on the left)

KK – gives the operation value

All CC, FF, or 00 – not applicable... always CC, FF or 00 as indicated

RS232 Program Protocol

- Command List

- Power on:

\$BE\$EF\$03\$19\$00\$00\$00\$01\$00\$02\$01\$00\$00\$00\$00\$00\$00\$00\$00\$00\$CC\$CC\$CC\$C
C\$CC\$CC\$CC\$CC\$CC\$CC\$CC\$CC

- Power off

\$BE\$EF\$03\$19\$00\$00\$00\$01\$00\$02\$01\$00\$00\$00\$00\$00\$00\$04\$00\$00\$00\$CC\$CC\$CC\$C
C\$CC\$CC\$CC\$CC\$CC\$CC\$CC\$CC

- change to AUTO

\$BE\$EF\$03\$19\$00\$00\$00\$01\$49\$10\$01\$00\$00\$00\$00\$00\$00\$00\$00\$00\$CC\$CC\$CC\$C
C\$CC\$CC\$CC\$CC\$CC\$CC\$CC\$CC

- change to VGA

\$BE\$EF\$03\$19\$00\$00\$00\$01\$49\$10\$01\$00\$00\$00\$00\$00\$01\$00\$00\$00\$CC\$CC\$CC\$C
C\$CC\$CC\$CC\$CC\$CC\$CC\$CC\$CC

- change to HDMI

\$BE\$EF\$03\$19\$00\$00\$00\$01\$49\$10\$01\$00\$00\$00\$00\$00\$02\$00\$00\$00\$CC\$CC\$CC\$C
C\$CC\$CC\$CC\$CC\$CC\$CC\$CC\$CC

- change to DVI

\$BE\$EF\$03\$19\$00\$00\$00\$01\$49\$10\$01\$00\$00\$00\$00\$00\$03\$00\$00\$00\$CC\$CC\$CC\$C
C\$CC\$CC\$CC\$CC\$CC\$CC\$CC\$CC

RS232 Program Protocol

- Command List

- Auto Adjust

\$BE\$EF\$03\$19\$00\$00\$00\$01\$02\$01\$01\$00\$00\$00\$00\$00\$01\$00\$00\$00\$CC\$CC\$CC\$C
C\$CC\$CC\$CC\$CC\$CC\$CC\$CC\$CC\$CC

- Lock Power

\$BE\$EF\$03\$19\$00\$00\$00\$01\$01\$01\$01\$00\$00\$00\$00\$00\$01\$00\$00\$00\$CC\$CC\$CC\$C
C\$CC\$CC\$CC\$CC\$CC\$CC\$CC\$CC\$CC

- Unlock Power

\$BE\$EF\$03\$19\$00\$00\$00\$01\$01\$01\$01\$00\$00\$00\$00\$00\$02\$00\$00\$00\$CC\$CC\$CC\$C
C\$CC\$CC\$CC\$CC\$CC\$CC\$CC\$CC\$CC

- Lock OSD

\$BE\$EF\$03\$19\$00\$00\$00\$01\$01\$01\$01\$00\$00\$00\$00\$00\$03\$00\$00\$00\$CC\$CC\$CC\$C
C\$CC\$CC\$CC\$CC\$CC\$CC\$CC\$CC\$CC

- Unlock OSD

\$BE\$EF\$03\$19\$00\$00\$00\$01\$01\$01\$01\$00\$00\$00\$00\$00\$04\$00\$00\$00\$CC\$CC\$CC\$C
C\$CC\$CC\$CC\$CC\$CC\$CC\$CC\$CC\$CC

- Lock Remocon

\$BE\$EF\$03\$19\$00\$00\$00\$01\$01\$01\$01\$00\$00\$00\$00\$00\$05\$00\$00\$00\$CC\$CC\$CC\$C
C\$CC\$CC\$CC\$CC\$CC\$CC\$CC\$CC\$CC

RS232 Program Protocol

- Command List

- Unlock Remocon

\$BE\$EF\$03\$19\$00\$00\$00\$01\$01\$01\$01\$00\$00\$00\$00\$00\$06\$00\$00\$00\$CC\$CC\$CC\$C
C\$CC\$CC\$CC\$CC\$CC\$CC\$CC\$CC

- Factory Reset

\$BE\$EF\$03\$19\$00\$00\$00\$01\$03\$04\$01\$00\$00\$00\$00\$00\$01\$00\$00\$00\$CC\$CC\$CC\$C
C\$CC\$CC\$CC\$CC\$CC\$CC\$CC\$CC

- OSD TIMEOUT

\$BE\$EF\$03\$19\$00\$00\$00\$01\$03\$03\$01\$00\$00\$00\$00\$00\$Control Level (5-60)
\$00\$00\$00\$CC\$CC\$CC\$CC\$CC\$CC\$CC\$CC\$CC\$CC\$CC\$CC\$CC

- SET ENGLISH

\$BE\$EF\$03\$19\$00\$00\$00\$01\$04\$01\$01\$00\$00\$00\$00\$00\$01\$00\$00\$00\$CC\$CC\$CC\$C
C\$CC\$CC\$CC\$CC\$CC\$CC\$CC\$CC

- SET FRANCAIS

\$BE\$EF\$03\$19\$00\$00\$00\$01\$04\$01\$01\$00\$00\$00\$00\$00\$02\$00\$00\$00\$CC\$CC\$CC\$C
C\$CC\$CC\$CC\$CC\$CC\$CC\$CC\$CC

- SET ESPANOL

\$BE\$EF\$03\$19\$00\$00\$00\$01\$04\$01\$01\$00\$00\$00\$00\$00\$03\$00\$00\$00\$CC\$CC\$CC\$C
C\$CC\$CC\$CC\$CC\$CC\$CC\$CC\$CC

RS232 Program Protocol

- Command List

- SET DEUTSCH

\$BE\$EF\$03\$19\$00\$00\$00\$01\$04\$01\$01\$00\$00\$00\$00\$00\$04\$00\$00\$00\$CC\$CC\$CC\$C
C\$CC\$CC\$CC\$CC\$CC\$CC\$CC\$CC\$CC

- SET NEDERLANDS

\$BE\$EF\$03\$19\$00\$00\$00\$01\$04\$01\$01\$00\$00\$00\$00\$00\$05\$00\$00\$00\$CC\$CC\$CC\$C
C\$CC\$CC\$CC\$CC\$CC\$CC\$CC\$CC\$CC

- SET POLSKI

\$BE\$EF\$03\$19\$00\$00\$00\$01\$04\$01\$01\$00\$00\$00\$00\$00\$06\$00\$00\$00\$CC\$CC\$CC\$C
C\$CC\$CC\$CC\$CC\$CC\$CC\$CC\$CC\$CC

- SET RUSSIA

\$BE\$EF\$03\$19\$00\$00\$00\$01\$04\$01\$01\$00\$00\$00\$00\$00\$07\$00\$00\$00\$CC\$CC\$CC\$C
C\$CC\$CC\$CC\$CC\$CC\$CC\$CC\$CC\$CC

- SET 10000K

\$BE\$EF\$03\$19\$00\$00\$00\$01\$05\$01\$01\$00\$00\$00\$00\$00\$01\$00\$00\$00\$CC\$CC\$CC\$C
C\$CC\$CC\$CC\$CC\$CC\$CC\$CC\$CC\$CC

- SET 9300K

\$BE\$EF\$03\$19\$00\$00\$00\$01\$05\$01\$01\$00\$00\$00\$00\$00\$02\$00\$00\$00\$CC\$CC\$CC\$C
C\$CC\$CC\$CC\$CC\$CC\$CC\$CC\$CC\$CC

RS232 Program Protocol

- Command List

– SET 6500K

\$BE\$EF\$03\$19\$00\$00\$00\$01\$05\$01\$01\$00\$00\$00\$00\$00\$03\$00\$00\$00\$CC\$CC\$CC\$CC\$CC\$CC\$CC\$
CC\$CC\$CC\$CC\$CC

- SET USER

\$BE\$EF\$03\$19\$00\$00\$00\$01\$05\$01\$01\$00\$00\$00\$00\$00\$04\$00\$00\$00\$CC\$CC\$CC\$CC\$CC\$CC\$CC\$
CC\$CC\$CC\$CC\$CC

- ADJUST CONTRAST

[illegible]

- ADJUST BRIGHTNESS

\$BE\$EF\$03\$19\$00\$00\$00\$01\$47\$02\$01\$00\$00\$00\$00\$00\$Adjust_Scroll_Change(0-100)
\$00\$00\$00\$CC\$CC\$CC\$CC\$CC\$CC\$CC\$CC\$CC\$CC\$CC\$CC

– ADJUST VOLUME

\$BE\$EF\$03\$19\$00\$00\$00\$01\$06\$01\$01\$00\$00\$00\$00\$00\$Adjust_Scroll_Change(0-100)
\$00\$00\$00\$CC\$CC\$CC\$CC\$CC\$CC\$CC\$CC\$CC\$CC\$CC\$CC

- MUTE ON

\$BE\$EF\$03\$19\$00\$00\$00\$01\$06\$02\$01\$00\$00\$00\$00\$00\$01\$00\$00\$00\$CC\$CC\$CC\$CC\$CC\$CC\$CC\$
CC\$CC\$CC\$CC\$CC

- MUTE OFF

\$BE\$EF\$03\$19\$00\$00\$00\$01\$06\$03\$01\$00\$00\$00\$00\$00\$01\$00\$00\$00\$CC\$CC\$CC\$CC\$CC\$CC\$CC\$
CC\$CC\$CC\$CC\$CC